

STEP 1:

Assemble frame and base using hardware provided.

STEP 2:

For maximum frame stability, face the large 1" hole opening on the steel pipes towards the interior of frame. The nut and washer are attached through the large hole opening (Figure A).

STEP 3:

Slip pillowcase net over frame and secure bottom sewn rope borders to steel tubing using zip ties.

ITEM NO.	DESCRIPTION	QTY.
1	INFIELD SCREEN BASE	1
2	WHEEL KIT AXLE BRACKET	2
3	1/2"-13 X 7 1/2" HEX BOLT (PARTIAL THREAD)	2
4	1/2"-13 JAM LOCK NUT	2
5	3/8" X .68" OD SPLIT LOCK WASHER	4
6	3/8"-16 X 3/4" HEX BOLT	4
7	6" X 2" FLAT FREE TIRE	2
8	1.66" X 16 GA X 66.50" L TUBE, SWAGED	2
9	1.66" X 16 GA X 29.0625" L TUBE, SWAGED	3
10	1.66" X 16 GA X 56" L TUBE	2
11	1.66" X 16 GA X 39.50" L TUBE, SWAGED	2
12	3/8"-16 X 2 1/2" HEX BOLT (PARTIAL THREAD)	10
13	5/16" X .875" OD WASHER	10
14	3/8"-16 LOCK NUT	10
--	7' X 10' SHAGGER SCREEN NET	1
--	8' ZIP TIE (NOT SHOWN)	20

