

STEP 1:

Assemble frame and base using hardware provided. Wheel kit sold separately.

STEP 2:

For maximum frame stability, face the large 1" hole opening on the steel pipes towards the interior of the frame. The nut and washer are attached through the large hole opening (Figure A).

STEP 3:

Slip pillowcase net over frame and secure bottom sewn rope borders to steel tubing using zip ties.

ITEM NO.	DESCRIPTION	QTY.
1	INFIELD SCREEN BASE	1
2	3/8"-16 X 2 1/2" HEX BOLT (PARTIAL THREAD)	8
3	5/16" X .875" OD WASHER	8
4	3/8"-16 LOCK NUT	8
5	1.66" X 16 GA X 66.50" L TUBE, SWAGED	2
6	1.66" X 16 GA X 29.0625" L TUBE, SWAGED	3
7	1.66" X 16 GA X 56" L TUBE	2
--	7' X 7' INFIELD SCREEN NET	1
--	8" ZIP TIE (NOT SHOWN)	20

(WHEEL KIT SOLD SEPARATELY)

8	6" X 2" FLAT FREE TIRE	2
9	WHEEL KIT AXLE BRACKET	2
10	1/2"-13 X 7 1/2" HEX BOLT (PARTIAL THREAD)	2
11	1/2"-13 JAM LOCK NUT	2
12	3/8" X .68" OD SPLIT LOCK WASHER	4
13	3/8"-16 X 3/4" HEX BOLT	4

