



# Adjustable Weight Nail Drag | Assembly Guide

**STEP 1:**

Use a hammer to tap the 4" nails into the nail boards. Proper orientation of nails and nail boards is critical.

**STEP 2:**

Slide the assembled boards into the channels of the main frame.

**STEP 3:**

Use hardware to bolt on weight mounts and pull brackets. Note orientation of pull brackets. The longer end should be located on the front side of the drag, with the nails angled away towards the back side.

**STEP 4:**

Attach the tow chain to the front side of the pull brackets using quick links.

The back side of the pull brackets can be used to secure a second drag, such as a cocoa mat or steel mat.

ITEM NO.	DESCRIPTION	QTY.
1	MAIN FRAME	1
2	NAIL BOARD	2
3	PULL BRACKET	2
4	WEIGHT MOUNT	3
--	ADJUSTABLE WEIGHT NAIL DRAG HARDWARE KIT	1
5	3/8"-16 X 2 1/2" CARRIAGE BOLT (PARTIAL THREAD)	6
6	3/8" X 1" OD FLAT WASHER	6
7	3/8"-16 LOCK NUT	6
8	4" NAIL	100
--	BEACON FIELD WEIGHTS (PKG OF 4)	2
9	FIELD WEIGHT	4
--	REPLACEMENT TOW CHAIN	1
10	1/4" CHROME PLATED STEEL CHAIN	1
11	1/4" WIDE-JAW QUICK LINK	3

